


# OWNER'S MANUAL



## SPARTAN VI



490 OBERLIN AVE. SO., LAKEWOOD, N.J. 08701

# INTRODUCTION

Your installer has selected one of the finest alarm systems available for your installation and has custom programmed system features to meet your specific requirements.

The SPARTAN VI alarm system was designed for high reliability, excellent security and simplicity of operation. These features make it easy for you to get the most out of your system and prevent false alarms.

The system is capable of reporting alarm and fault information via the telephone to a central monitoring station. Some of the functions that your installer might have programmed are: fire, burglary, entrance delays, exit delays, silent alarm, holdup, flooding, power failure, fire trouble and others. Consult with your installer and make sure you understand which ones are programmed and how they are used.

Paragraphs that are indicated by a  refer to options that may not apply to your system. Those  which your installer has marked with an "X" should be read as they contain information which pertains to your system.

## GENERAL DESCRIPTION

The SPARTAN VI alarm system has 6 zones that can be wired to external sensors. Alarms may be automatically initiated from these external sensors or manually initiated from the digital keypad.

Examples of external sensors are: magnetic switches, window foil, floor mats, light beams, intrusion detectors, heat sensors, smoke detectors, water detectors and others. Examples of keypad initiated alarms are shown on page 4.

The digital arming station displays system status and receives its commands from 1 or more digital arming stations. Each arming station consists of an amber status LED, 6 red zone LEDs, a 12 button keypad and a miniature piezo-alert. (See Figure 1)

Displayed zones may be 24 hour zones or switchable zones. \*24 hour ones are normally on continuously and cannot be switched off from the arming station. An example of a 24 hour zone would be a fire zone that provides 24 hour protection.

Switchable zones (usually burglar zones) can be switched on (armed) and switched off (disarmed) from the arming station. An example of a switchable zone would be a burglar zone assigned to the front door (usually an entrance, exit delay zone). A user can arm and disarm this zone allowing entrance to or exit from the premise.

## DISPLAY

The amber status LED indicates whether the panel is armed, disarmed or has a fault condition.

## SYSTEM DISARMED

When the amber status LED is off, burglar zones are disarmed and their associated zone LEDs indicate loop status (i.e. when on, door is opened; when off, door is closed).

## SYSTEM ARMED

When the amber status LED is on, burglar zone LEDs indicate which zones are on (armed). \*24 hour zones are normally always armed and their associated LEDs are on, unless a previous alarm condition has not been cleared. (Example: a smoke detector has not been reset) in which case the LED will be off, indicating that the zone is not armed and will not arm until the smoke detector is reset.

## FAULT CONDITIONS

A blinking amber status LED indicates a fault condition and the zone LEDs indicate the type of fault condition when the enter key is pressed.

There are three types of fault conditions: they are AC Power Failure, Low Battery and Fire Trouble.

The fault type may be determined as follows: When the amber status LED blinks press and hold the enter key. If zone 1 LED is lit the fault condition is AC power failure. If zone 2 LED is lit the fault condition is low battery and if zone 3 LED is lit then the fault condition is fire trouble. If more than one zone is assigned for fire then the faulted fire zone(s) may be found by pressing the mode key. The faulted zone(s) will be displayed on the zone LEDs.


\*Your installer may have allowed 24 hour zones to be bypassed to allow access to safes, vaults or tampered enclosures. **FIRE ZONES SHOULD NOT BE BYPASSED.**

When a fault is initiated the piezo-alert intermittently beeps until the enter key is pressed. The fault LED will continue to blink until the condition is corrected.

Armed/disarmed status can still be determined when the status LED is blinking. If the amber status LED is predominantly ON and momentarily blinks off, then the switchable zones are ON (armed). If the amber status LED is predominantly OFF and momentarily blinks on then switchable zones are OFF (disarmed).

## DISARMING


Disarming is accomplished by entering the four digit access code provided by your installer. To disarm your system (Assume Access Code 1234) enter your Access Code, key sequence as follows:



Your system is now disarmed. The amber status LED and all RED Burglary zone LEDs will be OFF.

## ARMING

To arm your system enter your Access Code key sequence as follows:



Your system is now armed. Amber status LED and all RED burglary zone LEDs will be on. The panel cannot be armed if a burglary zone is violated unless the violated zone is cleared or bypassed. WARNING: This system can be armed with the battery disconnected.

## ZONE BYPASSING

A zone may be bypassed by entering the zone number after the access code. For example the access code is 1 2 3 4 and zone 1 is to be bypassed: Enter the panel is now armed and zone 1 is bypassed. Subsequent violations of that zone will not trigger an alarm. Zone 1 LED will be off.

Your installer will advise which zone(s) can be bypassed.

## ALARM MEMORY


When an alarm condition occurs, the zone LED(S) will flash indicating which zone(s) were violated. They will remain on until the access code is entered.

## INSTANT/DELAY

Your installer may have assigned at least one zone as a delay zone and programmed delay times to allow you to enter and leave the premise.

The system should be in the delay mode when leaving the premise. This will delay arming, allowing time to exit. Your installer has programmed an Exit Delay time of \_\_\_\_\_ seconds. When entering, the alarm will be delayed and a pre-alert audible warning will sound allowing time to disarm the system. Your installer has programmed an Entrance Delay time of \_\_\_\_\_ seconds.

The instant mode is primarily used in residences. It is used during sleeping hours when a delay is not desirable. Delay zone(s) may be converted to instant zone(s) by using the following sequence:



Converting back to a delay zone(s) is accomplished by repeating the above sequence.

Although the Instant/Delay mode is not indicated by the LEDs, the user can determine which mode the panel is in by pressing the key. If a 3 second tone is heard from the piezo-alert after the key is RELEASED then the panel is in the delay mode. If no tone is heard after the key is RELEASED then the panel is in the instant mode. The user gets an indication of whether the system is in the instant or Delay mode each time the panel is armed.

The system is automatically set to delay mode when it is successfully disarmed from a previous armed state.

## FOLLOWER ZONES

A zone that has an intrusion detector can be programmed as a Follower Zone. This feature allows the system user to walk in front of the intrusion detector when entering or exiting the premise via an Entrance/Exit delay zone, without tripping the Follower Zone.

If the premise is entered through a zone other than a Delay zone and the Follower Zone is violated, then the Follower Zone will instantly go into alarm.

### KEYPAD INITIATED ALARMS

A list of keypad initiated alarm options are shown below.

- Bell test from keypad
- Duress from keypad
- Silent alarm from keypad
- Audible alarm from keypad (reporting)
- Audible alarm from keypad (non-reporting)
- Fire alarm from keypad (reporting)
- Fire alarm from keypad (non-reporting)




FIGURE 1

### DURESS (AMBUSH)

Duress is used during a hold-up when you're ordered to disarm your system. When used, a silent alarm is transmitted to the central monitoring station. Press  key after your Access Code, then press the  (ENTER) key. The system will disarm and a silent alarm will be transmitted.

There are four special alarms that can be initiated at the keypad. These alarm key pairs must be pressed simultaneously. The special key pair combinations are:

- |                          |     |                          |
|--------------------------|-----|--------------------------|
| <input type="checkbox"/> | and | <input type="checkbox"/> |
| <input type="checkbox"/> | and | <input type="checkbox"/> |
| <input type="checkbox"/> | and | <input type="checkbox"/> |
| <input type="checkbox"/> | and | <input type="checkbox"/> |

Consult your installer/dealer as to which one(s) of these are used, if any, and which combination indicates which alarm. The special symbols alongside of specific rows are to help you identify which keys to press in case of an emergency situation.

### AUDIBLE ALARM

Your installer has installed an audible alarm. This alarm has a different sound for fire and burglary. Burglary will have a steady sound and fire will have an interrupted sound.

### TESTING PANEL FUNCTIONS

Your alarm system and its associated components (intrusion detectors, smoke detectors, etc.) should be tested periodically. You can test most of the devices yourself. Example: The intrusion detector can be tested by disarming the system and walking or having someone walk in front of it. While observing its associated zone LEDs, the LED should go on and off showing that the intrusion detector and the connections to the panel are operational. The same can be done with doors, windows, etc. If in doubt as how to test associated devices, read the owner's manuals that accompany these devices or discuss with your installer.

### TESTING COMMUNICATOR

Check with your installer as to how to test, and how often to test the communicator portion of your SPARTAN system. Various central monitoring stations have different procedures for testing the communicator. Your installer is familiar with this procedure.

### TESTING BATTERY

The battery should be tested at least once a week in the following manner. Your installer has designated one of the special keypad key pairs as a bell test. This key pair combination should be pressed to initiate an alarm. While the alarm is ringing remove AC power. If bell output sound is lower when AC power is removed, call for service. When test is completed, enter access code at keypad to shut bell off.

### TESTING BATTERY AND BELL USING TEST/FIRE RESET SWITCH

Your installer has installed a Fire Reset/Test switch on the left side of your control panel. Pressing this switch will remove AC power and ring bell. Depress switch for at least ten (10) seconds and listen to bell. If bell output is reduced, call for service.