

4 + 2 Reporting Codes

Zone	Alarm	Trouble	Alarm Restore	Trouble Restore Fire Only
1	11	31	71	91
2	12	32	72	92
3	13	33	73	93
4	14	34	74	94
5	15	35	75	95
6	16	36	76	96
7	17	37	77	97
8	18	38	78	98
9	21	41	81	A1
10	22	42	82	A2
11	23	43	83	A3
12	24	44	84	A4
13	25	45	85	A5
14	26	46	86	A6
15	27	47	87	A7
16	28	48	88	A8
17	19	39	79	99
	2A	4A	8A	AA
95-Keypad	2C	4C	8C	AB
96-Keypad	2D	4D	8D	AC
99-Keypad	2B	4B	8B	AD
99-Keypad	2E	4E	8E	AE
D1 D2	Low Battery AC Loss			

This document was created with Win2PDF available at <http://www.daneprairie.com>.
The unregistered version of Win2PDF is for evaluation or non-commercial use only.