

Radionics Download Methods

	Ring Count	CMD 43	Answer Machine Defeat	RAM Line Monitor	Key 2
Radionics D4112	x	x			
Radionics D6112	x	x			
Radionics D8112	x	x			
Radionics D2412	x		x		
Radionics D2012	x		x		x
Radionics D2212	x		x		x
Radionics D2112					x
Radionics D7112	x			x	
Radionics D7212	x			x	
Radionics D7212B	x			x	
Radionics D7412	x			x	
Radionics D9112B1	x			x	
Radionics D9412	x			x	

Ring Count

Panel answers after pre-programmed number of rings. Most panels have separate ring counts for ARMED and DISARMED status.

CMD 43

Method 1 - RAM calls the panel. As soon as the line rings, enter [COMMAND][4][3] at the keypad. Panel answers and connects.

Method 2 - Call RAM phone number with a phone on panel phone line. RAM operator starts connection. When modem tone is heard, enter [COMMAND][4][3] at the keypad. Panel will seize the line and connect.

Answering Machine Defeat

Call the panel and ring twice.

Hang up.

Call the panel back (2nd time) and ring twice.

Hang up.

Call the panel back (3rd time).

Panel answers on first ring.

RAM Line Monitor

*Ram Line Monitor - If anyone or anything (like an answering machine) answers the phone and the panel hears the RAM tone, it will immediately seize the line and connect to RAM. If no one or no machine answers the phone. then the panel will answer after the ringcount is reached.

Key 2

If RAM Phone # is blank – After you press the 2-Key and enter your passcode, the panel seizes the phone line and waits for the remote programmer handshake.

If RAM Phone is programmed with a phone number – After you press the 2-Key, the panel seizes the phone line, dials the RAM Phone number and waits for the remote programmer handshake.

This document was created with Win2PDF available at <http://www.daneprairie.com>.
The unregistered version of Win2PDF is for evaluation or non-commercial use only.