Function Key Programming

1. Enter Program mode by entering your installers code + 8 + 0 + 0, or if you do not know the installers code you can power down & up then press [*] + [#] simultaneously within 50 seconds of power up.
2.

Start Function Key Programming mode by pressing ✱57 while in Data Programming mode. The following prompts are displayed:

PROMPT	VALID ENTRIES	EXPLANATION
Press Key to Pgm 0 = Quit 0	**Function Key** Press the desired function key, A-D. [✱] to continue	Press the desired function key (A-D) you want to program. **NOTE:** A key programmed as a function key is no longer available to be used as an end-user macro key or panic key.
Partition 1	**Partition Number** 1 = partition 1 2 = partition 2 3 = common partition [✱] to continue	Enter the partition in which the function key is active.
Key "A" Func Zone 95 00	**Define Key Function** 00-12 = see list to right [✱] to continue Returns to key number prompt with the next function key letter displayed. † System defaults to these function key settings. †† Macros 11-12 apply to VISTA-20P only.	Enter the desired function for this key, 00 to 12, from the options listed. (00 selected for example display shown at left) 00† = For the Function key selected, the function will be as follows: If A selected = Zone 95 (emergency key, same as [1] [✱] pair) If B selected = Zone 99 (emergency key, same as [✱] [#] pair) If C selected = Zone 96 (emergency key, same as [3] [#] pair) If D selected = Single-button paging 01 = Single-button paging (sends a 999-9999 message to pager) 02 = Display time 03 = Arm AWAY (reports as User 00 if closing reports are enabled) 04 = Arm STAY (reports as User 00 if closing reports are enabled) 05 = Arm NIGHT-STAY (reports as User 00 if closing reports enabled) 06 = Step Arming (arms STAY, then NIGHT-STAY, then AWAY) 07 = Device A ctivation (for device programmed as system operation type 66–function key in *80 Menu Mode) 08 = Communication Test (sends Contact ID code 601) 09 = Macro Key 1 (define macro by user code + [#] [6] [6] command) 10 = Macro Key 2 (define macro by user code + [#] [6] [6] command) 11†† = Macro Key 3 (define macro by user code + [#] [6] [6] command) 12†† = Macro Key 4 (define macro by user code + [#] [6] [6] command)

3. After programming the A-D keys has been completed, when keypad shows ‘Press Key to Prgm’ Enter 0, then press [*] to exit this menu mode.
4. Press [*] 99 to exit program mode.

NOTE: Press & hold the desired function key for 2 seconds to perform the programmed function.